

Cleaning and maintenance

Before cleaning, please cut off power firstly, use wet cloth clean the exterior, do not use containing mineral bubble to clean, avoid scratching.

Solving problems

Failure phenomenon	Probable cause	Method
Do not work after start up	Car head not inserted into the cigarette lighter	Insert tge car head again
Do not work after start up	Cigarette lighter poor contacting	Check car cigarette lighter if there is poor contacting
Have sound after start up	Vibration motor fault	Send for repair
Work only one time after start up	The fan voltage and car voltage does not match	Choose the right fan model for using

Dear users:

- Thank you for choosing our products.
- This product is a perfect design, high quality home appliances products. For your convenience, please read instructions carefully, and use according to the book's instructions.
- From beginning to end, we will provide high quality service for you. No matter what problem when you use, welcome to call our service phone, also you can contact the local service center.
- Thank you again for you to choosing our products. Due to improvements of the product, the Products you get may not in conformity with the specifications shown, Please understand.

Fresca NANO VEHICLE FAN




MANUAL

Technical specifications


Corresponding to different models, please refer to the corresponding parameters.



Model: ORA-NANO
Spec: 4 inch
Voltage: 12V
Power: 4W
Noise: <45db
Weight: 0.2 kg




Components



All-round adjustable.

Please do not rotate the fan if it is unnecessarily



ON/OFF Switch

Packing list

Fan / Super glue cushions(2pcs) / Manual

Note

- 1.After open the packing, please properly handle bags in order to avoid children or pets suffocation.
- 2.Before use, please place the fan smoothly.
- 3.Please do not place in much soot, dust places for using.
- 4.Do not use the fan pointed directly at the fire or gas for blowing, Do not put any metal or flammable items into the product, in order to avoid trouble and fires.
- 5.Do not use at places where near fire or has the high temperature, waste paper, scrap metal.
- 6.Do not dip part of fan or the whole machine into water for cleaning, when using in the outdoor if there is thunder, please stop using immediately, in order to avoid electric shock and fire.
- 7.The baby under adult supervision for using, please keep infants and young children far away from dry battery.
- 8.When cleaning, please do not directly spray the detergent to the fan, in order to avoid damaging the plastic parts.

Operating instructions

- 1.Before use, please turn off the switch.
- 2.Starting car, plug in the cigarette lighter.
- 3.Adjusting appropriate angle of fan, turn on the switch.
- 4.After using it, turn off the switch, and pull out cigarette lighter.