



TOW BALL WEIGHT SCALE

BN-THC350

INSTRUCTIONS



Start on a flat, level surface with brakes on and wheels chocked.

Check that the caravan or trailer is level, with the front and rear equally elevated, before placing the Tow Ball Weight Scale next to the caravan or trailer coupling.

Use the jockey wheel to raise the coupling, ensuring it is centered underneath.



Use the jockey wheel to slowly lower the coupling down onto the Tow Ball Weight Scale until the coupling comes into contact with the scale.

Be sure to check the scale is still centered and the base is resting flat on the level surface.

If the coupling is too high for the scale, try using a level block of wood to elevate the scale.




Slowly lower the coupling onto the Tow Ball Weight Scale until the jockey wheel no longer touches the ground.

Now that the weight from the caravan or trailer is transferred entirely onto the Tow Ball Weight Scale, an accurate reading can be taken.

Be sure to re-check weight after each change to the load or load distribution.

Only to be used as intended by the manufacturer; using for any other purpose could result in physical damage or personal injury.

Dimension drawing:



WARRANTY & PRODUCT INQUIRIES:

1 year warranty from date of purchase. For warranty evaluation, the purchaser must return the product to the dealer.

Manufactured by Team Noble Limited - +86 755 85278182

Australian distributor ONEX - (03) 8354 550

www.onex.com.au